

Low friction kit Page 1/2




- 1. Dismount the cover (A) on the spring side of the spool using a 5mm hexagon wrench.
- 2. Press the lever (B) to push the spool into it's end position and mount the spring holder (C) (can be bought separately) over the centering spring.
- 3. Use a 17mm socket wrench to loosen the spring bolt (D)
- **4.** Remove the lever link(E) and dismount the console(F), then carefully pull the spool out from the valve body.
- **5.** Unscrew the spring bolt (D) and separate the spring package (G) from the spool.
- **6.** Dispose the old glyd rings and o-rings (on both sides of the valve)(H).
- **7.** Mount the small supplied o-ring () inside the new glyd ring ().
- **8.** Mount the new seal () on the spring side of the spool.
- **9.** Compress the spring (k) by hand or with a fitting tool and remove it. Mount the new spring (labeled blue) in the spring holder (c), in the same way as the old spring.
- **10.** Remount the spring package (G) and tighten the spring bolt (D) by hand.



Low friction kit Page 2/2

Fits: Manual operated Q300, Q200 and Pv90 valves



- 11. Place the supplied grease (L) on the spring package and around the spool on both sides of the seal.
- **12.** Place the supplied supplied large o-ring in the cavity on both sides of the valve.
- 13. Gently push the spool back into the valve.
- **14.** Repeat step 7 and then push the new seal () onto the spool end.
- **15.** Place the supplied grease (L) around the spool on both sides of the seal and on the console.
- **16.** Remount the console (F) and the lever link (E).
- **17.** Tighten the spring bolt (D) with torque 6 ±1 Nm, before taking away the spring holder (C).
- **18.** Remount the spring cover(A).
- **19.** Repeat all steps on the remaining valve sections.

